



## **CLEANING GUIDELINES – Residential – weekly (or as required)**

**TO KEEP YOUR FLOORS SLIP RESISTANT AFTER APPLICATION, IT IS ESSENTIAL THAT THEY ARE CLEANED THOROUGHLY, OBSERVING THE FOLLOWING:**

1. Clean the floor with Wax and Grease remover (degreaser SlipStop S085) to remove heavy build-up and contamination. Dilute in hot water at 1:50. Apply with a mop on the surface.
2. Scrub the floor using a scrubbing brush, mechanical or manual.
3. Vacuum or mop up liquid off the floor once scrubbing is complete.
4. Once you have degreased the floor, using a different mop, apply (S055 Green Cleaner) dilute 1:50 in hot water to neutralise the wax and grease remover effects immediately after.
5. Mop up the green cleaner with a clean mop or vacuum.

### **Do not's**

**DO NOT** use an abrasive pad. This could damage your floor.

**DO NOT** use the same mop or scrubbing brush for both processes otherwise; you risk re-spreading the same “wax and grease” back onto the clean floor.

**DO NOT** use a powdered detergent – it will leave a calcite film on the surface of your floor.

**DO NOT** Polish or seal over your floor. This will stop the treatment from being effective

Never use a cleaner that leaves a film on your floor. Avoid cleaners containing sodium hydroxide or cleaners containing alkaline content. Mild organic cleaners are preferable.

If you have any questions or queries on maintenance, email [info@slipsafe.co.nz](mailto:info@slipsafe.co.nz)